


| HEATING | COOLING | HEAT PUMP | FAN | POWER |
|---|------------------------|--|-----|----------------------|
| 4 stages (HP, Emr heat, gas, dual fuel) | 1 and 2 stages (Y, Y2) | With auxiliary and emergency heat (O/B, W/E, W2) | (G) | (C, RH, RC, battery) |

PRODUCT SCHEMATIC



INSTALLATION INSTRUCTIONS

1. Mount the Sensi thermostat base on the wall using the supplied screws
2. Attach the appropriate wires to the corresponding Sensi thermostat wire terminals
3. Remove the battery tag and the attach cover
4. Download the Sensi app and create an account
5. Connect to the Sensi network using the mobile devices Wifi and enter the included Sensi password
6. In the app, select the home network and enter the network's password
7. Register the thermostat

SAFETY NOTES

- Always turn of the power to the heating and cooling system before handling the thermostat wires
- Make sure all wires are screwed in tightly and securely

